

TABLE OF CONTENTS

SECTION	TITLE	PAGE
	How to Use This Manual	i
1	Introduction	1-1
2	Identify / SetAll	2-1
3	Creating Symbols and Templates	3-1
4	Keyboard Macros	4-1
5	Productivity Macros	5-1
	• DCAD_AEC	5-2
	• EZ Tools	5-13
	• SteelPro	5-15
	• DuctPro	5-17
	• Annotate	5-20
	• Window Master	5-36
6	Importing & Exporting .DWG Files	6-1
7	Multi-Scale Plotting & Clip Cubes	7-1
8	External Reference Files (XREFs)	8-1
9	o2c (Objects to See)	9-1
10	Clip Cubes for 3D	10-1
11	Modeling With 3D Polygons	11-1
12	What Else is New in Version 10?	12-1
	• Layer Manager	12-2
	• Menu Hot Spots	12-4
	• Bitmap Import	12-4
	• Solid, Pattern and Bitmap Fills	12-8
	• Calibrated Enlargement	12-12
	• True Type Fonts	12-13

TABLE OF CONTENTS

SECTION	TITLE	PAGE
	<ul style="list-style-type: none">• Contour Search• Drawing Stamps• Aliases• Dimensions and Dimension Styles• Filled Arrowheads• Batch Plot Enhancements• Hyperlink Enhancements• Hatch Preview• General Enhancements	12-17 12-19 12-21 12-23 12-24 12-25 12-26 12-27 12-30
13	New Polyline Functions	13-1
14	What's On the CD-ROM?	14-1
	<ul style="list-style-type: none">• Homework• Viewlets• Toolbox Macros• Sample Files• .PEN Files• DataCAD LLC Web Pages• Adobe Acrobat Reader• ACAD to DCAD Hatch Converter• Organic CADD 3D Trees• WinTopo• OCE Plotter Drivers• Bitmap Textures• Layer Utility• ALT-Key Codes	14-1 14-2 14-2 14-2 14-2 14-2 14-2 14-3 14-3 14-3 14-3 14-4 14-4 14-4
